Instruction of Watch Movement

3 hands

◆ Display



◆ Crown operation

	Crown position	
	N : normal	1 : 1st click
Crown	Free	Time setting

◆ How to set time

(1) Pull the crown out to the 1st click position when the second hand is at the 12 o'clock position.

(2) Turn the crown to set the hour and minute hands.

- When setting the minute hand, advance it 4 to 5 minutes ahead of the desired time and then turn it back to the exact time.

(3) Push the crown back to the normal position.

◆ Power depletion warning function

When the battery nears its end, the second hand moves at two-second intervals instead of the normal one-second intervals. In that case, have the battery replaced with a new one as soon as possible.

- The watch remains accurate while the second hand is moving at two-second intervals.

Note : The availability of this function is different depending on the caliber.